

Part# CV461

Row: Rear- 60/40 Split Back & Solid Cushion

Application Available for: Chevrolet Equinox/GMC Terrain 2010

Parts included:

Backrests-2 Headrest-2

Installation Instructions

2121 South Anne Street Santa Ana, CA 92704

800-846-8621

For General Information or Warranty contact: support@caltrend.com

Bottom Cushion-2 Armrest-1



Part#CV461 Rear- 60/40 Split Back & Solid Cushion

Step #1- Prepare Seats

Remove headrest from mounts and set them aside.

Step #2-Install 60/40 Backrest

Pull the latch, located on top of the backrest, and push it forward. Place the cover over the backrest but under the safety restraint, matching its contours and cutouts. Tuck in the top piece of the cover, sending the velcro to the back.

Step #3- Install 60/40 Backrest

Zip the zipper and lift up the carpet. Pull the carpet from the back, and secure the fit by attaching the velcros together. Tuck in the bottom piece and send it to the back of the console. Then attach it onto the velcro of the backrest.



Lift and pull the seat off of its mount. Place the cover over the cushion, matching its contours, and cutouts. Tuck in the top piece of the cover, sending the buckles to the back.

Step#5- Install Cushion



Buckle the straps accordingly, make sure to pull on the straps tightly, so the cover is well fitted.

Step#6- Install Headrest



Place the cover over the headrest, matching its contours and cutouts. Make sure the solid piece is facing the front. Then secure the fit by attaching the velcros together.

Step#7- Install Armrest





Open the console, and place the cover over the armrest, matching its contours and cutouts. Tuck in the bottom piece of the cover sending the velcro to the back. Pull the velcro through the back, and secure the fit by attaching the velcros together.

Step#8- Finishing Touch



Once all covers have been installed adjust the seating and headrests to their regular position. Tuck all straps underneath the seating. Now you are ready to enjoy your CalTrend Seat Covers ©

**Enjoy your CalTrend Seat
Covers***

In case of dirty or stained covers hand wash with mild detergent and air dry. NEVER MACHINE WASH OR DRY. The material may come apart from lamination or foaming. This will also void any warranty.