

# Installation Instructions

## CV408 Custom Tailored Seat Cover

Type of headrests: Separate; armrests: Yes

**This Seat Cover will fit the following:**

2007-2010 Chevrolet Suburban 1500 (LT, LTZ)

2007-2010 Chevrolet Tahoe (LT, LTZ)

2007-2010 Chevrolet Yukon XL 1500, 2500 (SLE, SLT, DENALI)

### Parts Included:

Headrests- 2

Backrests- 2

Bottom Cushion- 2



2121 South Anne Street, Santa Ana, California 92704

800-846-8621

[www.caltrend.com](http://www.caltrend.com)

MADE WITH GREAT  
PRIDE IN THE

**USA**



# CV408 Custom Tailored Seat Cover Installation



**Step#1 - Remove Headrest**  
(Remove and Apply the headrest cover, attach the Velcro on bottom.)



**Step#2 – Install Backrest Part 1\***  
(Slip the cover onto the backrest and tuck in the flaps.)



**Step#3 – Install Backrest Part 2\***  
(Attach the Velcro and straps together on the back of the seat)



**Step#4- Install Bottom Cushion**  
(Tuck in the remainder of the fabric in between the plastic)



**Step#5- Install Armrest**  
(Slip cover over armrest backrest, attach velcro together.)



**Step#6- Flat folding**  
Note this is flat folding seating; driver side will be different than passenger side.



Made in the USA  
**CALTREND**  
Custom Seat Covers™

2121 South Anne Street, Santa Ana, California 92704

800-846-8621

[www.caltrend.com](http://www.caltrend.com)